





# 5MXM-A9



Product liability label

Manufacturer label


Outdoor air temperature thermistor



In case of removing the stop valve cover.

## Minimum space for air passage

Wall height on air outlet side < 1200 mm



Terminal strip with earth terminal

Room ·E·  
Gas stop valve  
·ø15.9· CuT

Room ·E·  
Liquid stop valve  
·ø6.4· CuT

Room ·A·  
Gas stop valve  
·ø9.5· CuT

Caution label

Room ·A·  
Liquid stop valve  
·ø6.4· CuT

Room ·B·  
Gas stop valve  
·ø9.5· CuT

Room ·B·  
Liquid stop valve  
·ø6.4· CuT


Room ·C·  
Gas stop valve  
·ø12.7· CuT

Room ·C·  
Liquid stop valve  
·ø6.4· CuT

Room ·D·  
Gas stop valve  
·ø15.9· CuT

Room ·D·  
Liquid stop valve  
·ø6.4· CuT

Service port



44

168